


6.5 Spare Parts



Nr.	Name	75	100	120
1.	Fuel Pump paraffin and diesel	GD3452	GD3452	GD3452
2.	Coupling motor/pump	IP200723	IP200723	IP200723
3.	Oil hose complete	GD3385	GD3385	GD3385
4.	Fan motor	GD4307	GD4307	GD4307
5.	Fan guard	GD4300	GD4300	GD4300
6.	Fan blade	IK4220	IK4212	IK4222
7.	Vane switch assembly	GD3409	GD3409	GD3409
8.	Ignition cable	GD3400	GD3400	GD3400
9.	Ignition electrode	IP3934	IP3934	IP3934
10.	Nozzle Diesel & Paraffin/kerosene	IP3249	IP3251	IP3232
11.	Burner stabilizer	GD200667	GD200667	GD200667
12.	C cone	GD2810	GD2810	GD2810
13.	After burner plate assembly	GD2812	GD2812	GD2812
14.	LDS photocell flame sensor	GD3380	GD3380	GD3380
15.	Burner control unit	GD5904	GD5904	GD5904
16.	Fan relay	IK5200	IK5200	IK5200
17.	Ignition transformer	GD3404	GD3404	GD3404
18.	Control box	GD4820	GD4820	GD4820
	Wire boom 230V	IP5914	IP5914	IP5914
	Wire boom 24V DXB	IP5918	IP5918	IP5918
	Service/Reset switch incl. Cover	GD3500	GD3500	GD3500